

How to Measure High Chlorine Levels

When reading a chlorine level at the high end of your test kit's range, the true chlorine level may be much higher. You will need to make a dilution to obtain a more accurate reading.

How To Make A Dilution:

1. Fill the test vial half full with pool water.
2. Finish filling the test vial with distilled or tap water.
3. Mix.
4. Add reagents.
5. Read and multiply result by 2.


Example:

If your diluted pool sample reads 4 ppm free chlorine, then the pool actually contains 8ppm. ($4 \text{ ppm} \times 2 = 8 \text{ ppm}$)

1/2 distilled water
or tap water



1/2 pool water



- Mix
- Add Reagents
- Read
- Multiply result by 2



Environmental Health Division
1101 W. College, Ste. 402
Spokane WA, 99201
324-1560, Ext. 4 TDD 1464
B&W/Water Rec/Dilution
Reviewed 3-2005

Always working for a safer and healthier community